

Raspberry Pi Adaptor Assembly

The mounting holes on the Raspberry are sligthly smaller than the screws. Use one of the screws to make it bigger by screwing it in and then out of the board.



Raspberry Pi Adaptor Parts



Screws and Nuts

2 M3 15 mm Screws and Nuts. 2 M3 20 mm Screws and Nuts.

